

# P. R. HAVENER

Warming churches

## Operating Instructions / Technical Data

### Communion wine warmer



Ice-cold communion wine is now a thing of the past.

Warm up the wine and / or drinking water to a pleasant temperature with our communion wine warmer before the church service starts.

A fibreglass-reinforced plastic mat with an integrated plastic surface heating conductor guarantees even homogeneous heat emission. Thanks to the washable, robust surface this approx. 2 mm thick product is particularly easy to clean and durable.

The communion wine containers are placed on the wine warmer before the church service begins. Depending on the ambient temperature, the wine / water warms up to a pleasant temperature after 10-30 minutes. A must-have in every sacristy.

#### **Technical data:**

- Dimensions: 27 cm x 27 cm
- Power: 15 Watt / 230 V
- Protection class: II
- Incl. insulation layer
- Connection: 1.5 m ribbon cable and plug
- Colour: light grey
- Usage: for heating communion wine and drinking water
- Simple installation: lay on or under - plug in – heat



# P. R. HAVENER

## Warming churches

### **Where you are not allowed to use the communion wine warmer:**

Communion wine warmers are not intended for outdoor use or in wet areas such as bathrooms, showers and the like.

The communion wine warmer is for use on tables or other flat surfaces only!

### **Commissioning:**

- Remove all sharp objects from the surface on which the warmer is to be placed.
- The communion wine warmer must not be placed on rough surfaces (e.g. grates, gravel paths and the like).
- The communion wine warmer must not be bent or rolled up strongly at low temperatures (below + 5°C).
- Remove the heater from the packaging, lay it out on a flat surface and plug the mains plug into the socket.
- Do not use in a folded or rolled state!
- Do not operate the wine warmer in the bath tube or shower!

### **Observe during operation:**

- Do not cover the wine warmer or place any furniture on it.
- Before use, check the communion wine warmer for foreign objects that have penetrated the warmer, e.g. tacks!
- Disconnect the mains plug from the socket before inspecting!
- CAUTION! Do not insert needles! Do not insert any sharp objects!
- In the case of automatic operation (time switches, ...), the function must be checked at appropriate intervals to avoid uncontrolled heating (e.g. continuous operation, heating in summer...).
- Run the mains cable along the floor (do not stretch it at a low height) to avoid the risk of stumbling.

### **Cleaning:**

- Always pull the mains plug out of the socket when cleaning!
- Do not wash in the washing machine!
- Do not pour water over the communion wine warmer or immerse it in water!
- Only wipe the plastic with a damp cloth.
- Do not use any chemicals that dissolve PVC! (e.g. acetone)

# P. R. HAVENER

## Warming churches

### **Transport - Storage:**

- Do not fold or bend the wine warmer!
- If possible, transport it flat.
- Do not hang the wine warmer on the mains cable or drag it.
- Our products are constantly being adapted to the latest state of the art, so changes must be expected.
- Therefore, please request new information material regularly!