

P. R. HAVENER

Warming churches

Operating instructions THERMOPLUSH HEATED CARPET

We are glad you have chosen to purchase a Thermplush heated carpet. Only high-grade materials are used in the manufacture of our heated carpets, so that your Thermoplush heated carpet will give you many years of pleasant warmth when used properly.

The following instructions are for your safety and should be observed precisely for this reason!



Do not use Thermoplush heated carpets in the following circumstances:

Thermoplush heated carpets are not intended for use outdoors or in wet rooms, such as bathrooms, showers and similar. Furthermore, Thermoplush heated carpets will not withstand wheelchair use and must not be used under office chairs with castors.

The undersides of Thermoplush heated carpets can become very hot! For this reason, do not place the heated carpets on surfaces that are over-sensitive to temperature.

Technical specifications:

- standard size: 70 x 100 cm or custom size
- wiring: 3.0 m flat ribbon cable and plug
- operating voltage: 230 volt
- output: 120 or 250 Watt per m² (recommended output on cold stone floors: 250 W/m²)
- colours: 56 shades acc. to colour chart
- areas of use: e.g. in front of altar
- easy to install: place in desired position - plug in - heat up

P. R. HAVENER

Warming churches

Commissioning:

Remove any sharp objects from the surface where the heated carpet is to be placed.

Do not use Thermoplush heated carpets on uneven surfaces (such as grating, gravel paths or similar).

Do not roll up Thermoplush heated carpets or bend them at sharp angles when temperatures are low (below +5°C).

Remove Thermoplush heated carpet from the packaging. Place on the floor with the carpet surface facing up and plug in.

Do not use when folded or rolled up!

Do not use Thermoplush heated carpets in the bath or shower!

When operating, pay attention to the following:

Do not cover Thermoplush heated carpets and do not place furniture on them.

Prior to use, check the Thermoplush heated carpets to make sure they have not been penetrated by any foreign bodies, e.g. drawing pins!

Unplug from mains before examining!

CAUTION! Do not insert pins/nails! Do not insert any sharp objects!

In automatic operation (timer switches etc.), it is necessary to check for good working order at appropriate intervals in order to avoid uncontrolled heating (e.g. continuous operation, heating in summer etc.)

CAUTION! Do not keep using heated carpets once the layer of plastic is visible through the carpet surface or if mechanical damage has occurred in the fabric casing.

Lay the mains cable flat on the floor (do not suspend just above floor) to avoid risk of tripping.

Cleaning:

Always unplug from mains before cleaning! Do not wash in the washing machine!

Do not pour water over the heated carpet or immerse the heated carpet in water!

Use standard carpet cleaning agents and vacuum cleaners to clean carpets.

Do not use any chemicals that dissolve PVC! (e.g. acetone)

Transport - storage:

Do not fold or bend Thermoplush heated carpets! Keep as flat as far as possible during transport. (If the carpet has to be rolled up, the bending radius should not be less than 15 cm.) Do not suspend Thermoplush heated carpets by the cable. Do not drag by the cable.

Our products are updated regularly to reflect the latest standards of technology so that changes must be expected.

Make sure you request new product literature regularly for this reason!

