

P. R. HAVENER

Warming churches

Technical specifications / operating instructions

Heated altar mats / organ pedal heating

Stops the organist's feet from getting cold and prevents hands from getting cold at the altar.

A glass-fibre-reinforced plastic mat with built-in plastic surface heating element ensures that heat is radiated in a more even and homogeneous way.

High-grade material and knowledge stemming from our many years of experience in the field of church heating systems are what makes this product (just around 2 mm thick) different.

Technical specifications:

- size: 60 cm x 100 cm (or custom size)
- output: 150 watt / 230 V (for a size of 60 cm x 100 cm)
- wiring: 2.5 flat ribbon cable and plug
- colour: pale grey
- areas of use: on the altar (under the altar cloth), under the organ pedal
- easy to install: place in desired position - plug in - heat up

Do not use organ pedal heating / heated altar mats in the following circumstances:

Organ pedal heating / heated altar mat is not intended for use outdoors or in wet rooms, such as bathrooms, showers and similar.

The organ pedal heating / heated altar mat is only intended for use on altars or under organ pedals.

Commissioning:

Remove any sharp objects from the surface where the heating is to be placed.

Do not use the organ pedal heating / heated altar mats on uneven surfaces (such as grating, gravel paths or similar).

Do not roll up the organ pedal heating / heated altar mats or bend them at sharp angles when temperatures are low (below +5°C).

Remove heating from the packaging. Spread out and place on the surface to be heated and plug in.

Do not use when folded or rolled up!

Do not use organ pedal heating / heated altar mats in the bath or shower!

When operating, pay attention to the following:

Do not cover the organ pedal heating / heated altar mat and do not place furniture on them.

Prior to use, check the organ pedal heating / heated altar mat to make sure they have not been penetrated by any foreign bodies, e.g. drawing pins! Unplug from mains before examining!

CAUTION! Do not insert pins/nails! Do not insert any sharp objects!

In automatic operation (timer switches etc.), it is necessary to check for good working order at appropriate intervals in order to avoid uncontrolled heating (e.g. continuous operation, heating in summer. etc.)

Lay the mains cable flat on the floor (do not suspend just above floor) to avoid risk of tripping.

P. R. HAVENER

Warming churches

Cleaning:

Always unplug from mains before cleaning! Don't wash in the washing machine! Do not pour water over the organ pedal heating / heated altar mat or immerse in water!

Only wipe plastic with a damp cloth.

Do not use any chemicals that dissolve PVC! (e.g. acetone)

Transport - storage:

Do not fold or bend the organ pedal heating / heated altar mat! Keep as flat as far as possible during transport. (If the heating has to be rolled up, the bending radius should not be less than 15 cm.)

Do not suspend organ pedal heating / heated altar mats by the cable. Do not drag by the cable.

Our products are updated regularly to reflect the latest standards of technology so that changes must be expected.

Make sure you request new product literature regularly for this reason!

Examples of use

